


*STAFIX®GRIP is a glue-free sticker material that adheres to various clean and very smooth surfaces with a silicon adhesion layer. The material is removable without leaving any residue and reusable even up to 12 months.*

## USE



**12M**

STAFIX®GRIP adheres to various clean and very smooth surfaces, such as:

- glass
- stainless steel
- tiles
- plastic
- aluminium
- varnished wood

Thanks to the material's versatility, it can be used in various applications, such as:

- Retail advertising (e.g. freezers and -fridges)
- Store decoration and window display
- Events and exhibitions

## INSTALLING STAFIX®GRIP

*White & Clear*



**1** Make sure the surface is clean. If needed clean the surface but do not use detergent or chemicals. Wet installation\* is recommended to eliminate possible air bubbles more easily. Apply the film always from the unprinted side.

**2** Release carefully the liner (see other side for details) from the face of the film, and apply the upper corner to the surface where the artwork will be displayed. After the material is aligned, remove the liner working from the top to bottom.



**3** Use a soft sided "felt" squeegee to eliminate any air bubbles. Do not use of bubble popper tools or sharp objects to eliminate the bubbles.

***This use & installation guide is recommended to be provided by printing houses with the ready, printed products.***

## MIRROR-WISE PRINTED STICKERS



If you want to display the image through a glass window from inside to the outside (Shop display) you should use the clear film. The film should be printed 'mirror-wise', so that the unprinted side will adhere to the glass. The film will stick on the inside of the window with visibility from the outside.

## WET INSTALLATION



Wet installation makes the artwork easier to move and replace without damaging it during the installation process.

Make sure the surface is clean. Wet the clean surface with a spray bottle, place the desired artwork to the surface and use a soft sided "felt" squeegee to eliminate any air bubbles and remove the excess water moving from the center of the artwork to the sides. Wipe the excess water off with a paper towel.

## REMOVING THE LINER



The liner can be removed from the backside (from the unprinted side), using the tip of your thumb instead of your nails.

You can also remove the liner with a small piece of tape. Place the tape on the corner of the artwork's liner and pull the tape back so that the liner comes off.