

Scotchgard™ Paint Protection Film Pro Series 4.0 Scotchgard™ Paint Protection Film Pro Series 200 Gloss Scotchgard™ Paint Protection Film Pro Series 200 Matte 3M™ Paint Protection Film Series 100 Gloss

Scotchgard™ Paint Protection Film Pro Series 200 Gloss and Scotchgard™ Paint Protection Film Pro Series 200 Matte are referenced as Scotchgard™ Paint Protection Film Pro Series 200 in this document.

Installation Solutions

The slip solution must be prepared fresh every day. Do not store overnight!

Slip Solution

Scotchgard™ Paint Protection Film Pro Series 200

DI water, distilled water or filtered water	32 ounces or 1000 ml	or	DI water, distilled water or filtered water	32 ounces or 1000 ml
Johnson's® Baby Shampoo	1.5 - 2 ml*		Dawn® dish soap	1 ml

Slip Solution

3M™ Paint Protection Film Series 100 Gloss

DI water, distilled water or filtered water	32 ounces or 1000 ml	or	DI water, distilled water or filtered water	32 ounces or 1000 ml
Johnson's® Baby Shampoo	1 - 1.5 ml*		Dawn® dish soap	0.75 ml*

Slip Solution

Scotchgard™ Paint Protection Film Pro Series 4.0

DI water, distilled water or filtered water	32 ounces or 1000 ml	or	DI water, distilled water or filtered water	32 ounces or 1000 ml
Johnson's® Baby Shampoo	2.5 ml*		Dawn® dish soap	1.25 ml*

* Suggested solution mix starting points. In a hot environment, always keep the paint protection wet.

Alternatively, in hot environments:

- Add 0.5 - 1.0 ml more soap to the mix for Scotchgard™ Paint Protection Film Pro Series 200 and 3M™ Paint Protection Film 100 Gloss.
- Add 2 - 3 ml more soap for Scotchgard™ Paint Protection Film Pro Series Gloss or Matte.

3M™ Paint Protection Film Installation Gel

- Alternative slip foundation to water/shampoo solutions
- High viscosity water-based gel
- Ready to use



Tack Solution

Isopropyl alcohol (Isopropanol) 99%	150 ml	or	Isopropyl alcohol (Isopropanol) 70%	250 ml
DI water, distilled water or filtered water	850 ml		DI water, distilled water or filtered water	750 ml

Hybrid Solution

Johnson's® Baby Shampoo	2 ml	or	Johnson's® Baby Shampoo	2 ml
Isopropyl alcohol (Isopropanol) 99%	150 ml		Isopropyl alcohol (Isopropanol) 70%	250ml
DI water, distilled water or filtered water	850 ml		DI water, distilled water or filtered water	750ml

Installation Tools

Tools to use for a proper paint protection film installation:

- Disposable Syringes 5 ml
- Scotch-Brite® Microfiber Cloth
- 3M™ Perfect-It™ Cleaner Clay or Meguiar's® C2000 Pro Detailing Clay (Mild)
 - Optimal: 3M™ Surface Preparation System (Available in EU)
- 3M™ Paint Protection Film Installation Gel
- Turbo Squeegees or Fusion Squeegees
- Cutting knife 30-degree blades

Cap Sheet

The cap sheet layer helps protect the film's quality and is easily removed. Cap sheet pulls off by hand on bulk installation and needs to be removed before plotter cutting.

Roll Handling and Storage

Important Note

To prevent possible tunneling, hold the core of the roll and pull the film firmly, ensuring no slack. Then add tape in the middle of the tightened roll and within approx. 150 mm (6") of each roll edge. If the roll is 1,524 mm (60") wide, add two more pieces of tape approx. 450 mm (18") on either side of the center tape. Other roll dimensions are to be handled accordingly. Stand partial rolls straight up and down on a rack or similar.

Installation Instructions

- 1) Make sure there is no ceramic coating applied to the vehicle paint. If there is, ceramic coating can be removed by working with an authorized paint correction specialist/automotive detailer.
- 2) Use an adhesive remover solvent (3M recommends General Purpose Adhesive Cleaner) to remove any surface residue not removed in the cleaning process (i.e. wax, tar, paint sealant).
- 3) Use a non-ammonia foaming glass cleaner to remove any solvent residue from the adhesive cleaner. 3M recommends foaming glass cleaner.
- 4) Use a clay bar to remove surface contaminants on the painted surface. 3M recommends any mild clay bar such as 3M™ Perfect-It™ Cleaner Clay or Meguiar's® C2000 Pro Detailing Clay (Mild).
- 5) Wipe down the vehicle with a non-abrasive cloth and do a final inspection prior to the installation. 3M recommends Scotch-Brite® Microfiber Cloth.
- 6) After installation is complete, gently wipe down the film, dry, and inspect. Allow 15 minutes for the adhesive to dry before putting pressure on the film to avoid leaving marks.

Bulk Installation

For a bulk installation, dry areas that may have been exposed to excess slip when making anchor points on an install. For example, when stretching four corners for a bulk hood install. Wipe off any slip solution or flush out any slip solution and dry off in non-active area anchor points on the bumper or fender as you stretch the Scotchgard™ Paint Protection Film Pro Series 200 or 3M™ Paint Protection Film Series 100 Gloss over the hood and lock it in place. Hold for ten seconds to activate the firmer adhesive to stretch out any fingers and lock the four anchor points in place with warm water or tack solution.

ONLY for Scotchgard™ Paint Protection Film Pro Series 4.0

Use Meguiar's® Ultimate Quik Detailer™ (hydrophobic polymer wax) or Meguiar's® Final Inspection to gain more adhesive working time on paint protection films for larger automotive areas, such as hoods. DO NOT INSTALL ANY HYDROPHOBIC POLYMER WAX ON THE EDGES OF ANY INSTALLATION AREA OR WRAPPED EDGE. IF ANY HYDROPHOBIC POLYMER WAX GETS ON THE EDGES REMOVE IT BEFORE INSTALLING.

ONLY for 3M™ Paint Protection Film 100 Gloss and Scotchgard™ Paint Protection Film Pro Series 200

For application over a complex curve: activate the adhesive with "Tack Solution" and hold the film in place for at least 10 seconds. Warm water can be utilized in solutions to assist as needed with installation.

Application Temperature

Recommended application temperature: 60°F – 85°F (16°C – 30°C)

IMPORTANT: 3M recommends ease of application at +70°F to 79°F (+21°C to +26°C) for optimum application for paint protection film and vehicle.

Maintenance, Cleaning and Removal

- 3M recommends waiting at least 72 hours before washing a vehicle after paint protection film application.
- Touchless car wash and hand washing are preferred methods.
- Loose paint protection film could tear away from a moving vehicle. After washing, check all the paint-protecting films carefully for edge lifting and repair, and remove or replace damaged paint protection films.
- If a pressure washer is to be used, follow strict guidelines. However, aggressive washing can damage the paint protection film. Excessive pressure during power washing can damage the paint protection film by forcing water underneath the film and lowering the adhesion to the paint surface, causing the film to lift or curl. These problems are magnified by the wind.

To avoid edge lifting or other damage to the paint protection film, follow these important steps:

- Use a spray nozzle with a minimum 40-degree wide spray pattern.
- Be sure the spray nozzle includes a nozzle protector (tip guard).
- Use a maximum pressure of 80 bar.
- If the system is heated, limit the water temperature to 140°F (60°C) or less.
- Hold the nozzle at least 30 cm away from and perpendicular (90 degrees +/- 10) to the paint protection film, or a minimum of 100 cm away from the graphic at a 30° angle, or higher.
- Do not direct the water stream between 0° and 60° to the edge of the paint protection film.

The surface of the paint protection film is coated with a clear coat. This protects the surface to a high degree against environmental influences and mechanical stress. A commercial shampoo can be used for regular cleaning.

Do not use strong alkaline, acidic, or alcoholic cleaning agents. They could permanently damage the film.

Waxing

Regular treatment of the surface with a polish or wax is not necessary.

If waxing, do not use wax that contains dyes, abrasive polishes, and/or rubbing compounds. The abrasive particles will damage the film surface and result in a loss of surface quality.

Removal

3M recommends using a steamer for removal. The correct angle of removal is 30 – 60 degrees from the surface of the paint.

Factors that Affect Paint Protection Film Performance Life

The actual performance life of a paint protection film is affected by:

- Selection, condition, and preparation of the substrate
- Surface texture
- Application methods
- Environmental conditions

Health and Safety

When handling any chemical products, read the manufacturer's container labels and the Safety Data Sheets (SDS) for important health, safety and environmental information.

[Follow the link to obtain SDS sheets for 3M products on 3M.com/SDS.](#)

[Follow the link to obtain information about substances of very high concern \(SVHC\).](#)

IMPORTANT! When using any equipment, always follow the manufacturer's instructions for safe operation.

Limited Remedy

This bulletin provides technical information only. 3M recommended product end uses are listed in each 3M product bulletin. End uses not listed in the applicable 3M Product Bulletins are typically not eligible for 3M Warranties. For non-recommended and/or non-warranted end uses or applications, users must test and approve the end uses or applications, assume any associated risks, and acknowledge that 3M has no liability for such end uses or applications. Please contact your 3M representative with any questions about film applications, end uses, and warranties.

Limitation of liability

All questions of warranty and liability relating to this product are governed by the terms and conditions of the sale, subject, where applicable, to the prevailing law.

3M, Scotch-Brite, and Scotchgard are trademarks of 3M. All other trademarks are the property of their respective owners.

3M United Kingdom PLC

Commercial Branding & Transportation Division
Cain Road
Bracknell, RG12 8HT
UK
www.3m.co.uk

3M Ireland Ltd.

The Iveagh Building
The Park, Carrickmines
Dublin 18
Ireland
www.3m.co.uk

© 3M 2023. All rights reserved.